


H709 - Control Shelf


for Heckler AV Cart




Designed & made in Arizona
Patented

Mounting options


A Horizontal




B Angled



C Vertical




D Flipped




IN THE BOX


- A** 1 x Control Shelf for Heckler AV Cart
- B** 2 x Cart-mounting wingnuts
- C** 4 x Cart-mounting screws
- D** 1 x Cart-mounting assembly key
- E** 1 x Velcro for strapping devices. 12 inches.



**COMPONENTS NEEDED
(Not Included)**



Heckler AV Cart



Controller





PTZ Camera

If you have any questions, please contact
service@hecklerdesign.com.

STEP 1



Fasten Control Shelf to Heckler AV Cart.



Hold the shelf at the desired installation angle as you insert the lower screw.

STEP 2


Mount controller.





For Logitech Tap, use the mounting screws included inside of Tap's underside panel. For Neat Pad, use the M4 mounting screws included in Neat Pad's packaging.

OPTION

Mount camera.



Note that the center slots include 1/4" clearance holes for camera mounting.



*Camera-mounting screws not included.

OPTION

Manage cables with included Velcro strap.

